



Sluiten - Closing - Schliessen




Revisie 9 – 26-06-2018

LIGHTRONICS B.V.
Spuiweg 19
5145 NE Waalwijk, NL
Postbus 150
5140 AD Waalwijk, NL

Tel: +31(0)416 568 600
Fax: +31(0)416 568 601
E-mail: info@lightronics.nl
www.lightronics.nl



Kegelarmaturen algemeen
Montagehandleiding - Installation instructions - Montageanleitung



KFK
KBM
GFK
GBM
CPT
PKS



HHW
PHW



PRT
PTK
SGR



RMB





Disclaimer

NL- Alle informatie, ontwerp en specificaties die in deze handleiding zijn opgenomen waren ten tijde van publicatie correct. Echter, omdat het product continu in verbetering is, kan het uiteindelijke product enigszins afwijken van de functionaliteit die in deze handleiding is vermeld.


EN- All information, design and specifications in this manual, were correct when published. Yet: because this product is constantly being improved, the final product can be slightly different to the functionality that is represented in this manual.

DE- Alle Informationen, Design und Spezifikationen in dieser Anleitung waren korrekt zur Zeit Publikation. Dennoch: weil dieses Produkt konstant verbessert wird, kann das endliche Produkt etwas anders sein als in dieser Anleitung dargestellt ist.


Hoofdafmetingen (mm) - Main dimensions (mm) - Hauptabmessungen (mm)

	KBM	GFK	GBM	CPT	PKS	HHW	PHW	PRT	PTK	SGR	RMB
∅	600	690	690	490	600	585	585	600	585	540	585
H	495	440	480	340	420	1075	795	550	505	715	520
	0,15	0,18	0,17	0,11	014	026	021	0,15	0,17	0,17	019
	8	8	8	7	8	8	8	8,5	8	8	8

Montage op mast Ø60 - Mounting on pole Ø60 - Montage auf Mast Ø60




Aansluiten bekabeling - Installing wiring - Anschliessen Leitung



N = blue
 L = brown
 ≡ = yellow/green

Openen armatuur - Opening luminaire - Öffnen Leuchte



Unitplaatwissel - Unitplate replacement - Unitplatte Wechsel

